

POLYSALES
RECOMMENDED
VINYL FLOORING
INSTALLATION
TOOLS



# Flooring Contractor's/Fitter's Site Checklist

### SITE AND MATERIALS

Site conditions must be conducive to receive vinyl flooring. All screeds must be assessed for levelness (SANS 10155:2009) and moisture readings (75% RH or lower) must be conducted.

Understand your plan and layouts and ensure your material quantities are correct.

Check the colour, batch numbers and roll sequence numbers.

All material must be laid in batch number and roll sequence group number order.

If any material or colour faults are identified, immediately stop laying the material.

In addition, call your material supplier. No claims on installations of faulty material in excess of 100m2 will be considered.

If possible, allow the material to acclimatise and relax at least 24 hours prior to installation

Site conditions are very important. It is preferable that other trades are not working in the same area to prevent dust or contamination of the area, adhesives, and flooring.

Keep your work area clean and dust free.

# **INSTALLATION, ADHESIVES & WELDING**

Request the product specific installation guide is sourced from Polysales.

Ensure the correct adhesive and recommended trowel are used and that no trowel marks are mirrored through. Once adhesive is applied, use a mohair roller to flatten trowel marks. Cut the factory edge off by 5mm.

Overlap and scribe to achieve a tight joint. Roll sheeting or tiles with a 68kg roller.

Groove 2/3rds through the sheeting with a grooving tool.

Weld the sheeting at the correct temperature and speed.

trimmer). Cut the weld with a cutting slide and allow to cool down for at least 1 hour (we recommend the Mozart speed

Do the final cut.

Hot knifing will not be accepted when welding.

Hot knifing will not be necessary if the procedures are followed correctly.

New PUR speed nozzles are now available from our supplier.

## MAINTENANCE AND SEALERS

Identify your product finish e.g. PUR, PU or non-coated and apply recommended sealer if requested by client.

Ensure your client is in possession of the correct maintenance procedure relevant to the product installed

## WARRANTY CRITERIA

warranty is issued All Polysales recommended screed, moisture barriers, adhesives, testing & installation tools, installation guides, maintenance procedures, product specifications and general guidelines must be followed to ensure a Polysales

No claims will be entertained if any deviations from the Polysales guidelines have been identified




#### **MOISTURE TESTING**





**Moisture Testing Liquid** 





FLOOR GRINDING MACHINES & VACUUMS



AVC 38 Wet & Dry Vacuum





#### RIP UP TOOLS & SCAPERS



**Heavy Duty Scraper** 



Floor Scraper

**Heavy Duty Scraper** 





#### **CLEANING TOOLS**



Broom



Vacuum Cleaner



#### TESTING THE LEVELNESS OF SCREED





KU/Q Meter



#### SELF-LEVELLING SCREED APPLICATION



Rake








#### **MEASURING & CUTTING**













Tape Measures & Chalk Line

Squares



#### CUT OFF FACTORY EDGE





Factory Edge Cutter



Steel Hand Roller



#### ADHESIVE APPLICATION -**TROWELS & SPREADERS**



Spreader



Floor Roller – 68kg



**Knee Pads** 



Adhesive Trowel - 28cm

Mohair Roller



#### **GROOVING**





**Electrical Groover** 









Reducer Nozzle



Speed Welding Nozzle



**Electrical Welding Machine** 



#### TRIMMING THE WELD









**Mozart Speed Trimmer** 



CONTACT DETAILS

TEL: 011 609 3500

E - M A I L : M A R K E T I N G @ P O L Y S A L E S . C O M



Charles Davids (Technical Manager)



Leroy Arendse (Technical Consultant)