

Resistance to chemicals is tested over a 24 hour contact period at room temperature, followed by rinsing with cold water. Polyflor Ltd believe this simulates the worst situation where spillages are not removed immediately and are only cleaned by normal maintenance.

U – Unstained

A - Slight stain

B - Moderate stain

C - Heavy stain

E - Appearance as above plus slight surface disturbance

Chemical	Polyflor EC	Polyflor Conductive ROF
1 Acetic Acid Glacial	U	A
2 Acetic Acid 50% Solution	U	U
3 Acetic Acid 10% Solution	A	U
4 Boric Acid 10% Solution	U	U
5 Citric Acid 10% Solution	U	A
6 Hydrochloric Acid Concentrated	U	U
7 Hydrochloric Acid 50% Solution	U	U
8 Hydrochloric Acid 10% Solution	U	U
9 Lactic Acid Concentrated	A	A
10 Nitric Acid Concentrated	AE	AE
11 Nitric Acid 50% Solution	U	A
12 Nitric Acid 10% Solution	U	A
13 Oxalic Acid 10% Solution	A	AE
14 Perchloric Acid 60% Solution	A	A
15 Phosphoric Acid Concentrated	A	AE
16 Phosphoric Acid 50% Solution	A	A
17 Pyrogalllic Acid	A	A
18 Sulphuric Acid Concentrated	A	AE
19 Sulphuric Acid 50% Solution	A	A
20 Sulphuric Acid 10% Solution	A	A
21 Tannic Acid 10% Solution	U	U
22 Tartaric Acid 10% Solution	U	U
23 Thioglycollic Acid Concentrated	U	A
24 Absolute Alcohol	U	A
25 Amidol 10% Solution	A	A
26 Ammonia Solution 88	U	U
27 Ammonium Alum 10% Solution	U	U
28 Ammonium Bichromate 10% Solution	U	U
29 Ammonium Bromide 10% Solution	U	U
30 Ammonium Carbonate 10% Solution	U	A
31 Ammonium Chloride 10% Solution	U	U
32 Ammonium Sulphate	U	U
33 Ammonium Thiocyanate 10% Solution	U	U
34 Borax 10% Solution	U	U
35 Calcium Chloride 10% Solution	U	A
36 Calgon 10% Solution	U	A
37 Carbon Tetrachloride	U	A
38 Catechol 10% Solution	U	A
39 Chrome Alum 10% Solution	U	U
40 Copper Sulphate 10% Solution	U	A
41 Ferric Ammonium Citrate 10% Solution	U	U
42 Formaldehyde 50% Solution	U	U
43 Glycerine	U	U
44 Glycine 10% Solution	U	U
45 Hydrogen Peroxide 100%	U	U
46 Hydroquinone 10% Solution	A	A
47 Hydroxylamine Hydrochloride 10% Solution	A	A
48 Iodine 5% Soln In 10% Potassium Iodide soln	U	A
49 Iodine Alcoholic Solution 5% in Propan-2-ol	A	A
50 Iron Perchloride 10% Solution	A	A
51 Iron Sulphate 10% Solution	U	A

Chemical	Polyflor EC	Polyflor Conductive ROF
52 Lead Acetate 10% Solution	U	A
53 Magnesium Sulphate 10% Solution	U	U
54 Metol 10% Solution	A	AE
55 Mercuric Chloride 10% Solution	U	A
56 Methylated Spirits 10% Solution	U	U
57 Paraformaldehyde 10% Solution	U	U
58 Phenol 10% Solution	U	A
59 Potassium Bromide 10% Solution	U	A
60 Potassium Carbonate 10% Solution	U	U
61 Potassium Dichromate 10% Solution	U	U
62 Potassium Ferricyanide 10% Solution	U	U
63 Potassium Ferrocyanide 10% Solution	U	U
64 Potassium Hydroxide 10% Solution	U	U
65 Potassium Iodide 10% Solution	A	A
66 Potassium Metabisulphite 10% Solution	A	U
67 Potassium Oxalate 10% Solution	U	U
68 Potassium Permanganate 10% Solution	U	B
69 Potassium Thiocyanate 10% Solution	A	A
70 Silver Nitrate 10% Solution	A	A
71 Sodium Acetate 10% Solution	U	A
72 Sodium Bicarbonate 10% Solution	U	U
73 Sodium Bromide 10% Solution	A	A
74 Sodium Carbonate 10% Solution	U	U
75 Sodium Chloride 10% Solution	U	A
76 Sodium Hydroxide 10% Solution	U	A
77 Sodium Hypochlorite 10% Solution	A	A
78 Sodium Perborate 10% Solution	U	U
79 Sodium Phosphate 10% Solution	U	U
80 Sodium Sulphate 10% Solution	U	U
81 Sodium Sulphite 10% Solution	U	A
82 Sodium Thiosulphate 10% Solution	U	U
83 Blood	U	U
84 Urine	U	U
85 Izal Bleach Citrus, Concentrated	U	U
86 Izal Bleach Citrus, Diluted (10% Solution)	U	U
87 Lysol Concentrated	U	U
88 Izal Disinfectant Pine, Concentrated	U	U
89 Lysol Dilute	U	U
90 Printol Concentrated	U	U
91 Printol Dilute	U	U
92 TCP Concentrated	U	U
93 Dettol Concentrated	U	U
94 Soap Solution (Deb 2000)	U	U
95 Detergent (Daz Automatic, 10% Solution)	U	U
96 Milk	U	U
97 Tea (black)	U	U
98 Coffee (black)	U	U
99 Petrol	U	U
100 White Spirit	U	U
101 Diesel Fuel	U	U
102 Mineral Oil (Singer)	U	U
103 Vegetable Oil	U	U
104 Anti Freeze (Bluecol)	U	U